

## Protocol of XRD-Analysis

Company: Keramik-Institut; Ossietzkystr. 37a; D-01662 Meißen  
 Phone: +49 3521-463-510 or 515  
 Our Sample-No. X077/20/01 *KI 488/20*  
 Method: X-Ray Diffractometry / Triple preparation  
 Customer: Elektrokераmik Sonneberg  
 Arrival: 22.06.2020

Sample	Quartz	Feldspar	Corundum	Mullite	Residue*
	weight%				
<b>T30 02.06.20</b> <b>(Order No. 600632)</b>	< 1 (ca.0,8)	< 2	40	12	48

**\*Residue:**

- X-ray amorphous parts
- analytical mistake

Meißen, 30.06.2020  
 Rüdiger Köhler